

Installing Your Softwall Curtains

The first step in installing your softwall curtains is to lay out your track and mount the rear piece in the appropriate fashion.

Your track will be one of the following:

Flatwall Hook Bead

Anodized aluminum extrusion with flat edge for mounting to vertical surfaces. Secure to framing or wall with the hardware provided.



In-Jamb Hook Bead

Anodized aluminum extrusion with 90° flange to mount to horizontal surfaces. Secure underneath header beam, door jamb, or ceiling with hardware provided.



Flatwall with T-Bar Clips

Flatwall hook bead track with 1", 1½", or 2" T-bar clips to fit around existing grid. Eliminates need for drilling into ceiling. Available with cross grid angles for when running across a grid as opposed to in-line with it.



Once you have familiarized yourself with the track and laid the individual pieces out where they will need to go, you are ready to begin installation.

Step 1

Mount the rear piece of the track. Hardware is provided for attachment to virtually any surface. Self-drilling screws will attach to metals, lags will attach to wood, plastic anchors + lags will attach to concrete (Pre-drill ¼" hole in concrete).



Step 2

Unroll your new softwall panels and hook the bead into place on the track. Overlaps are automatic and strips are aligned every time. Any wrinkles from shipping will relax in a few days.



Step 3

Attach the cover piece of the track to the rear piece with the #10 x 3/8" machine screws provided. Use thumbscrews in the threaded holes to lock curtain in. Your installation is complete!

