

Recommended Materials

- Green Clean or Clear Clean
- Applicator bottle to evenly and efficiently apply cleaner.
- Squeegee (optional)
- Mop and/or Sponge

Cleaning Instructions

- Mix cleaning solution in an applicator bottle in a ratio of 1 part cleaner to 4 parts water.
- Apply an even amount of cleaner over the CleanPro® CleanTack sticky mat. Avoid creating pools or puddles.
- Mop the cleaner off in a direction away from clean area. Use short, firm, even strokes, systematically moving across the mat. Extra attention may be needed for high traffic or high contamination areas.
- Thoroughly rinse and ring the mop out with warm water. Use a damp mop over the mat to remove any surplus cleaner. Remove any cleaner on any exposed flooring around the mat as well.
- Let the mat air dry. A squeegee can be used if faster drying is necessary.

Additional Information

- Use Green Clean for daily cleaning.
- Use Clear Clean for high traffic or high contamination applications, as well as monthly cleaning.
- **Do not use cleaning machines, heavy, rough scouring powder, waxes or heavy solvent based cleaners.**
- **Use caution, mats are slippery when wet.**

