

TECHNICAL DATA SHEET

Part#: 500-92-US

Pliers - Form Dog Leg - ★★★★★ - Carbon Steel - TO-92 Lead Former

The 500-92-US five star 5.5" TO-92 lead forming plier has slots on the outside jaw to help the plier fit between the leads of a TO-92 and flare them out .050" forming a "Stand-Off" in the lead wires. It features a molded static dissipative (10⁸ ohms/sq) ergonomic grips with dual leaf springs.

• Precision Level	★★★★★
• Material	Carbon
• Surface Resistivity	10 ⁸ ohms/sq
• Shape	Straight
• Group	Pliers
• Tip Size (CTM)	x
• Jaw Angle	
• Jaw Length	
• Body Width	0.42" (10.5mm)
• Body Height	0.25" (6.25mm)
• OAL	5.5" (137.5mm)
• Weight (OZ)	5
• UPC	662847006807
• Schedule B	8203.20.60.30
• ECCN	EAR99
• UNSPSC Code	
• Country of Origin	USA

500-92-US Lead Forming Pliers TO-92 component

