



5" ESD Safe Flush Tapered Head Side Cutter with Wire Holder

Item No: 2476TX1W

5" ESD Safe Flush Tapered Head Side Cutter with Wire Holder

The Weller Erem Series 2400 Magic Sense is a range of medium-sized precision cutters that combines robustness, visibility and accessibility. A large variety of head shapes for precision work in hard-to-reach areas. The optimized ergonomic shape of the Series 2400 MagicSense prevents hand fatigue. These cutters are manufactured from improved induction-hardened cutting edges up to 64 - 65 HRc for an extremely long service life. The cutting edges are made from special tool steel. The precision cutters have a nonreflecting surface, are ESD safe and resharpenable.

KEY FEATURES

- + The jaws of the cutter have straight edges and taper to a point. This head shape allows access to difficult to reach areas but reduces the cutting capacity in comparison to the same size oval head cutter.
- + Series 2400 MagicSense model
- + W : Safety device for holding wire scraps
This safety device for side cutters holds wire scraps securely after cutting. Available for all Series 500, 600, 2400 & 2600 cutters. Order suffix "W", e.g.595EW
- + Carbide cutter 2476TX1 + "W" = wire holder

TECHNICAL DATA

Application	Microelectronic
Cut Type	Flush
Cutting Capacity - Copper	0.039 in
Cutting Capacity - Hard Wire	0.015 in
Cutting Capacity - Medium Wire	0.019 in
Cutting Edge Length	0.3 in
ESD Safe	Yes
UPC	037103300928