TRANSFORMING TECHNOLOGIES

OUTSTANDING ALTERNATIVES IN STATIC CONTROL

9010 Series ESD Jackets Medium Weight with Knit Cuffs

Level Three ESD Protection, At Level One Prices.

Transforming Technologies 9010 Series ESD Jackets provide high quality ESD protection at a great value! 9010 jackets are fabricated from light weight 90% polyester and 10% carbon fabric for unmatched operator comfort. Features a snap front closure, ESD knit cuffs, three roomy patch pockets and lapel style collars. The 9010 Series garment maintains consistent continuity readings after 100 wash cycles. Available in blue, black, white, teal and maroon.

The 9010 Series ESD Jackets have been independently tested and proven to meet the requirements for all three ESD garment categories defined by ANSI/ESD S20.20-2014 including the Groundable Static Control Garment System which is the most stringent of the garment resistance requirements.

Meets or exceeds requirements of ANSI ESD-S20.20 and the recommendations of ESD 4.1.



Specifications:	Part Numbers:
Meets: ANSI/ESDS20.20 &	JKC9021LB Lapel Collar, Knit Cuff, Light Blue, XS
ANSI/ESD STM2.1	JKC9022LB Lapel Collar, Knit Cuff, Light Blue, S
Material: 90% Polyester,	JKC9023LB Lapel Collar, Knit Cuff, Light Blue, M
10% Carbon	JKC9024LB Lapel Collar, Knit Cuff, Light Blue, L
Weave: Knitted-4bar	JKC9025LB Lapel Collar, Knit Cuff, Light Blue, XL
Weight: 120g/M	JKC9026LB Lapel Collar, Knit Cuff, Light Blue,2XL
Width: 142cm	JKC9027LB Lapel Collar, Knit Cuff, Light Blue,3XL
Tensile Strength	JKC9028LB Lapel Collar, Knit Cuff, Light Blue,4XL
- Warp 20.8Kg	JKC9029LB Lapel Collar, Knit Cuff, Light Blue,5XL
- Fill 31.2Kg	
Surface Resistance Below	Replace "LB" with "BK" for Black, "WH" for White, "MR" for
10^6Ω	Maroon, "TL" for Teal.



Features

- Extremely Comfortable & Durable
- Knit Cuffs For Hands-Free Grounding
- Reliable Panel-to-Panel Continuity
- Surface Resistance: <10^6Ω
- Three Patch Pockets
- Colors: Blue, Black, White,

Applications:

ESD jackets creates provides a Faraday cage effect and shields ESD susceptible items from charges on workers' clothing. They are used manufacturing, laboratory and assembly areas.

This document is prepared for our customers as a service, and is to the best of our knowledge true and accurate. However, it is understood and agreed by the users of this document that we will accept no liability for the conclusions reached. Users of this document may therefore wish to perform additional testing before determining that products mentioned are suitable.

Apparel