



Technical Data

Color	Royal
Sizes Available	XS-5XL
Packaging	Case
Packed	1/Case
Case Dimensions (in)	24.02 x 15.98 x 12.01
Case Weight (lbs)	2.01
Country of Origin	Mexico
Clothing Type	Lab Coats
Fabric	StatStar
Closure	Snap
Construction	ESD Safe
Certifications	TAA Compliant
Product Circularity	Reusable / Launderable

Uniform Technology™ StatStar Long ESD Labcoat

- StatStar Fabric - 87% Polyester / 13% Carbon
- Lapel collar
- Three patch pockets
- Snaps at front opening
- Grounding snap on waist pocket
- Snap wrist closure
- Snap wrist closure
- Pass-throughs slits at waist for pocket access
- ESD safe compliance to ANSI/ESD S20.20-2014 - Groundable Static Control Garment

Performance Data

ISO Cleanroom	--
ANSI/ESD S20.20	Groundable Static Control Garment < 1x10 ⁹ Ω Point to groundable point
Temperature Resistant	--
Static Control Property	Static Dissipative

Care Instructions

Our garments do not come wearer ready meaning they need to be laundered before an employee wears them in an ISO class cleanroom. Average wear and tear lifespan is 50-100 washes. Make sure all zippers and snaps are closed. Use less harsh soap (milk alkaline or neutral soaps) or detergents. Wash at 120°F for colors and 140°F for whites. Rinse cold. No bleach. Tumble dry moderate (140°F). After drying tumble dry cold for 5 minutes. No iron.



SKU Information

SKU	COLOR	SIZE	UPC	UPC (INNER)	UPC (CASE)
BR51-44RB-XS	Royal	XS	616314484438	10616314484435	20616314484432
BR51-44RB-S	Royal	S	616314484360	10616314484367	20616314484364
BR51-44RB-M	Royal	M	616314484339	10616314484336	20616314484333
BR51-44RB-L	Royal	L	616314484292	10616314484299	20616314484296
BR51-44RB-XL	Royal	XL	616314484391	10616314484398	20616314484395
BR51-44RB-2XL	Royal	2XL	616314484209	10616314484206	20616314484203
BR51-44RB-3XL	Royal	3XL	616314484223	10616314484220	20616314484227
BR51-44RB-4XL	Royal	4XL	616314484247	10616314484244	20616314484241
BR51-44RB-5XL	Royal	5XL	616314484261	10616314484268	20616314484265



Technical Data

Color	White
Sizes Available	XS-5XL
Packaging	Case
Packed	1/Case
Case Dimensions (in)	24.02 x 15.98 x 12.01
Case Weight (lbs)	2.01
Country of Origin	Mexico
Clothing Type	Lab Coats
Fabric	StatStar
Closure	Snap
Construction	ESD Safe
Certifications	TAA Compliant
Product Circularity	Reusable / Launderable

Uniform Technology™ StatStar Long ESD Labcoat

- StatStar Fabric - 87% Polyester / 13% Carbon
- Lapel collar
- Three patch pockets
- Snaps at front opening
- Grounding snap on waist pocket
- Snap wrist closure
- Pass-throughs slits at waist for pocket access
- ESD safe compliance to ANSI/ESD S20.20-2014 - Groundable Static Control Garment

Performance Data

ISO Cleanroom	--
ANSI/ESD S20.20	Groundable Static Control Garment < 1x10 ⁹ Ω Point to groundable point
Temperature Resistant	--
Static Control Property	Static Dissipative

Care Instructions

Our garments do not come wearer ready meaning they need to be laundered before an employee wears them in an ISO class cleanroom. Average wear and tear lifespan is 50-100 washes. Make sure all zippers and snaps are closed. Use less harsh soap (milk alkaline or neutral soaps) or detergents. Wash at 120°F for colors and 140°F for whites. Rinse cold. No bleach. Tumble dry moderate (140°F). After drying tumble dry cold for 5 minutes. No iron.



SKU Information

SKU	COLOR	SIZE	UPC	UPC (INNER)	UPC (CASE)
BR51-44WH-XS	White	XS	616314484643	10616314484640	20616314484647
BR51-44WH-S	White	S	616314484629	10616314484626	20616314484623
BR51-44WH-M	White	M	616314484612	10616314484619	20616314484616
BR51-44WH-L	White	L	616314484605	10616314484602	20616314484609
BR51-44WH-XL	White	XL	616314484636	10616314484633	20616314484630
BR51-44WH-2XL	White	2XL	616314484544	10616314484541	20616314484548
BR51-44WH-3XL	White	3XL	616314484568	10616314484565	20616314484562
BR51-44WH-4XL	White	4XL	616314484575	10616314484572	20616314484579
BR51-44WH-5XL	White	5XL	616314484582	10616314484589	20616314484586