

TECHNICAL DATA SHEET

Part#: 277-CE-ET

Tweezers - Straight - Ceramic Tips - Ergo
Heat Resistant (2000°F) - Ergonomic ESD Safe grips for comfort

The 277-CE-ET white Zirconia ceramic tipped tweezer is 5.5" long. The tip size is 0.04" wide and the shank is made of nickel silver, which is non-magnetic. Zirconia ceramic is six times harder than stainless steel, non-magnetic and chemically inert. Solder will not adhere to the surface. They have a working temperature of over 2000°F. It features our Ergo-Tweeze[®] soft cushioned Anti-Static grips (10¹⁰ ohms/sq surface resistivity), which also protect the user from heat.

• Precision Level	★★★★★
• Material	Ceramic Tips
• Surface Resistivity	10 ¹⁰ ohms/sq
• Shape	Straight
• Tip Size	.04" x .008" (1mm x .2mm)
• Tip Angle	Straight
• Tip Length	
• Body Width	0.75" (18.75mm)
• Body Height	0.5" (12.5mm)
• OAL	5.5" (137.5mm)
• Weight (OZ)	1.5
• UPC	662847005633
• Schedule B	8203.20.20.00
• ECCN	EAR99
• UNSPSC Code	27112105
• Country of Origin	Switzerland
• Group	Ceramic Tipped

