

MicroCare®



Uncured Epoxy Cleaner- Expoxy™ Presaturated Wipes



- The strongest stencil cleaner and degreaser
- Removes uncured epoxy, cured chip bonder, grease, solder paste, light oils and some inks
- Dissolves both organic and inorganic deposits, some acrylic
- No rip. No Lint. Heavy-duty wipe
- Unique “slam-shut” packaging for extra long service life

Product Information

Uncured Epoxy Cleaner-*Expoxy™*, is a versatile cleaner optimized for the removal of uncured epoxy from misprinted boards, stencils and squeegees. Using strong, shred-proof disposable wipes saturated in a powerful cleaning fluid, it quickly removes uncured epoxy resins with minimal effort. Also suitable for cleaning lead-free fluxes and pastes, water-soluble pastes and “no-clean” pastes. In its liquid form, it is a cost-effective choice for use in automatic stencil printers as it requires less solvent due to its highly activated chemistry. This formulation has been tested and accepted by DEK, EKRA, MPM and Panasonic for use in their stencil printers. Uncured Epoxy Cleaner-*Expoxy™* is the ideal choice for perfectly clean stencils and screens.

Money-saving refills are available only from MicroCare (image to the right). These contain the same wipes and fluid as the tubs above, but reduce costs and help protect the environment by encouraging the re-use of packaging.

AVAILABILITY: Stocked locally by MicroCare distributors world-wide. Contact MicroCare for a distributor

near you. For more information contact MicroCare directly or visit www.MicroCare.com.

MicroCare Corporation

595 John Downey Drive
New Britain, CT 06051 USA
Tel: 860.827.0626
Fax: 860.827.8105
Toll-Free: 800.638.0125
Email: TechSupport@MicroCare.com

MicroCare Europe Bvba

Havendoklaan 19, Cargovil
Vilvoorde, B-1804 Belgium
Tel: +32 2 251 95 05
Fax: +32 2 400 96 39
Email: EuroSales@MicroCare.com

Technical Details and Cleaning Data

Boiling Point	248-302°C / 120-150°F
Chemical Family	Alcoxypropanols
Cleaning Strength (KB value)	90 (est.)
Evaporation Rate	Moderate
Percent Volatile	100%
Odor	Mild Alcohol

Health, Safety and Environmental Data

Flammable	Yes
Flashpoint	41°C / 106°F
NFPA	Health: 0 Fire: 2 Instability: 0
Organic Content (g/L)	860
RoHS and WEEE Complaint	Yes
REACH	Yes*
US EPA SNAP-Approved	Yes

GHS / HCS Pictogram



Packaging

Presaturated Wipe Container	100, 5" x 8.5" wipes
443 mls fluid content	MCC-EPXW
Presaturated Wipe Refills	100, 5" x 8.5" wipes
443 mls fluid content	MCC-EPXWR
MiniCube	6 lbs / 2.72 k.MCC-EPXG
Cubitainer	32 lb / 13.6 k.MCC-EPXP
Drum	355 lb / 177.8 k.MCC-EPXD



Money-saving refills reduce costs and help protect the environment by encouraging the re-use of packaging.

Discover Perfectly Clean
www.MicroCare.com